

## RL504 CW WHITE (R)

L7221

### Details

#### Fitting instructions for ceramic waste kits

After taking the waste kit apart you need to put the white plastic chamber and the black rubber washer on the under side of the main bowl using a silicone sealant on the surface between the top of the rubber washer and the underside of the bowl. Also use silicone sealant on the under side of the metal flange going inside the bowl to provide a sufficient seal then using the centre bolt provided tighten it all up as tight as you can forcing any silicone sealant out and wipe the excess away. We also recommend you use some sealant on the overflow to prevent any leaking from here as well. Do the same procedure for the half bowl if you have purchased a 1.5 bowl sink. If you have a single bowl just follow the instructions above.



<b>New product number</b>	R25543
<b>Depth</b>	170 mm
<b>Old product number</b>	L7221
<b>Outlet</b>	3,5" outlet
<b>Cabinet</b>	800 mm
<b>Type</b>	Square sinks, Sinks with drainer
<b>Sink unit dimensions</b>	390 x 340 mm
<b>Colour ceramic</b>	White
<b>Total dimensions</b>	1000 x 500 mm
<b>Installation method</b>	Inset

### Related Products



**WOLGA chrome**

K755K

ONDERDEEL VAN  
**Ter Steege Groep**

