

## INSTALLATION INSTRUCTIONS FOR CONVECTOR HEATER GUARD

Part Number: CG2N0030

PLEASE RETAIN THIS LEAFLET FOR FUTURE MAINTENANCE

### CONVECTOR HEATER GUARD

The heater guard is designed for use with Consort CN2 and other convectors. Provision has been made for controls mounted on the side of the unit, with a cover plate supplied to restrict access to the controls via an M4 pan head Pozidrive screw.

### MOUNTING INSTRUCTIONS

1. Locate the template supplied centrally on the top of the wall mounted convector heater and mark the 2 top fixing holes. This will ensure that the guard is central and at the correct height.
2. Drill the 2 marked holes to suit No 8 wood screws and insert rawlplugs.
3. Fit and tighten screws until the heads are approximately 10 mm from wall.
4. The guard can now be located and 4 external fixing holes marked.
5. Remove guard and drill holes to suit No 8 wood screws and insert rawlplugs.
6. Locate guard and fix securely in place using 4 x No 8 wood screws.

